



COIN MECHANISMS INC.

Where The Money Meets The Machine

PO Box 5128, 400 Regency Drive, Glendale Heights, IL 60139-5128 VOICE: 630/924-7070 1-800-323-6498 FAX: 630/924-7088

ATTENDANT TERMINAL (02062AM)

USER MANUAL



Attendant Terminal

Setup

Plug the coaxial end of the power supply into the **Attendant Terminal** and plug the other end into the wall outlet. The unit will immediately power up and the VFD will display the **Version** and **Box ID** momentarily followed by the message to **Insert Key**

```
Version 2.20  
Box ID: 00001
```

```
DebitKey  
Insert Key
```

Locking/Un-locking

The **Attendant Terminal** powers up in the **Locked** mode to deter theft. When in this mode, the buttons are dis-abled preventing the ability to add value to a key. To Un-lock the terminal, insert an **UNLOCK** key into the key-port slot. The VFD now displays a **U** at the end of the second line of the VFD indicating that the terminal is now Un-locked. Alternate insertions of the **UNLOCK** key will toggle the terminal between Locked and Un-locked mode.

```
DebitKey  
Insert Key      U
```

Adding/Removing UNLOCK Keys

The **Attendant Terminal** can store up to three **UNLOCK** key serial numbers. When a new **UNLOCK** key is inserted for the first time, the key serial number is recorded in memory and the VFD displays the message **Key Saved**.

```
DebitKey  
Key Saved
```

If an **UNLOCK** key has been lost or stolen, it is necessary to remove the serial number of that key from memory. Using the keys with the other two serial numbers, insert one of the keys immediately followed by the other key. The VFD will display the message **Key Erased** indicating that the serial number of the lost/stolen key has been purged from memory.

```
DebitKey  
Key Erased
```

Attendant Terminal Cont'd

Checking Key Value

To check a **Debit** key value, insert the key into the key-port slot. The VFD will display the value of the key followed by the message **Locked** if the terminal is locked. If the terminal is un-locked, the VFD will display the value of the key followed by the message **Amount to Add?** indicating that the terminal is ready to add value to the key

```
Key = $20.00  
Locked
```

```
Key = $20.00  
Amount to Add?
```

Re- Charging Keys

With the terminal in the **Unlock** mode (as shown), insert a **Debit** key into the key-port slot. the VFD will display the value of the key followed by the message **Amount to Add?**. Press the button corresponding to the value that you wish to add to the key. Each time the a button is pushed the message displaying the key value will increase that amount.

```
DebitKey  
Insert Key      U
```

```
Key = $20.00  
Amount to Add?
```

Maximum Limits

Debit keys have a lifespan of 48—56 re-charges. Each time a value key on the terminal is pressed, this counts as a re-charge. If a key has used up all of it's re-charges, and you check or try to add value, the VFD will display the message Key Error.

```
Key =$20.00  
Key Error
```

Debit keys can store up to a maximum of 511 credits. Multiplying the value of each credit by 511 will give you the maximum value that can be stored. If you try to add value to a key that has reached maximum value, or if you try to add a value to a key that would cause it to exceed the maximum value, the VFD will display the message **Invalid Amount**.

```
Key = $126.00  
Invalid Amount
```

Attendant Terminal Cont'd

Show Totals


The **Show Totals** key can be inserted in either the Locked or the Un-locked mode. Insert the key into the key-port slot to display the **Current Total** (value accrued since this total was last cleared) and the **Running Total** (non-resettable)



DebitKey
\$45 \$63

Clear Total

The **Clear Total** key can be inserted in either the Locked or the Un-locked mode. Insert the key into the key-port slot to clear the **Current Total**.



DebitKey
\$0 \$63